

**DME's must be shipped to us in order to be programmed. Please follow the instructions below.**

**LOCATING THE MOTRONIC (DME) UNIT:**

The Motronic (DME) is an unpolished silver metal box approximately 18cm x 16cm x 4cm (6"x5"x2") labeled "MOTRONIC" either embossed or with a sticker. It is located under the driver's seat; remove the floor mat to locate it.

**TOOLS NEEDED FOR REMOVAL:**

Small Ratchet (socket wrench), Small Flat Head Screwdriver and a 10 mm socket with extension (1.5 inches long).

**REMOVING THE MOTRONIC (DME) UNIT:**

1. Slide the driver's seat back all the way back and up (if possible). Remove the floor mat.
2. Loosen the 4 nuts attached (10 mm).
3. Slide the Motronic slightly forward.
4. Remove the wiring harness connector by removing the retaining bracket (held in by a 10 mm washer and nut).
5. Remove the nuts and lift the unit off of the studs.
6. Hold the Motronic (DME) with one hand. Flip the steel retaining tab back that holds the connector.
7. Disconnect the box from the wiring plug by rotating the box out, away from the retaining tab.

**SHIPPING THE DME:**

Please handle the DME with care. An electrostatic bag is ideal to ship the DME in. Please box it up with plenty of packing material and send it to our U.S. address (If in North or South America) or our German address (if in Europe). Typical turnaround time is 5 business days.

FVD Brombacher, Inc. (USA)  
5061 NW 13th Ave. STE A  
Pompano Beach, FL 33064  
USA  
Phone: 1-954-571-2050

FVD Brombacher, GmbH (Germany)  
Waldmatten 2  
Umkirch  
79224  
Germany  
Phone: +49-7665-989-90